

Air Dam Installation Instructions DG812-S

'94-'01 Dodge Ram Truck

(fits '99-'02 One Ton) - (does not fit '99-up Sport)

Warranty is void if Air Dam is not prefitted to factory bumper before painting and installing.

Tools needed: 7/16 open end wrench or socket
#30 Torx Bit

1. Using a #30 Torx Bit with wrench, remove the factory Air Dam.
2. Position Air Dam aligning the center hole of Air Dam with the center hole of bumper.
3. Using a bolt with flat washer on the bolt, push bolt up through Air dam into bumper.
4. Install a locking nut from above. DO NOT tighten at this time.
5. Install the balance of the bolts making sure that a flat washer is against the Air Dam.
6. Once all bolts are installed, tighten starting from the center of the Air Dam working right and then center of the Air Dam working left.

Fog Light Installation Instructions

Tools needed: 7/16 open end wrench or socket

1. Discard all mounting hardware that comes with the Driving Light Kit except two black 1/4X1/2 Hex Bolts and wire connectors.
2. Insert Driving Light into light pocket shown in "Figure A".
3. Align holes in Driving Light with holes in Air Dam light pocket. Using black Hex Bolts supplied with Driving Lights, and 1/4 nuts and flat washers supplied with Air Dam bolt kit, fasten light as shown in "Figure B".

