

Air Vent Intake Scoop for '98-'05: Textured Black or Carbon Fiber Look

1. Clean entire cowl area from the front of the windshield to the front of the edge of the cowl between the hood hinges. Clean with soap and water. Rinse well and dry. Then clean with isopropyl alcohol or denatured alcohol. Wipe dry with a CLEAN DRY cloth.

NOTE: DO NOT REMOVE RED PROTECTIVE TAPE FILM FROM THE HOOD SCOOP UNTIL LAST STEP.

2. Measure and mark the center of the Air Vent Intake Scoop flange. Use a grease pencil or a small piece of masking tape or something that will not mar the painted surface. Find and mark the center of the front of the Jeep cowl and back edge of the Jeep hood. You can use the screw head that holds the factory air vent as a reference guide.

3. Now dry fit the Air Vent Intake Scoop and make any additional guide marks you need for centering and proper alignment. The front edge of the scoop will align with the front edge of the Jeep cowl approx. 1/16" behind the cowl edge.

4. Next peel back the red protective tape approx. 1" from each corner of the Scoop and fold the tape so that you make a pull tab that extends past the outer edge of the Air Vent Intake Scoop flange approx. 1/2"-3/4".

5. Lightly place and align the Air Vent Intake Scoop on the cowl, making sure that you can grab each one of the tape film tabs. Once in desired location, gently push down on the corners of the Scoop. Once secured in place, pull the tabs removing the protective film from under the Scoop. When all film is removed, push down firmly on the entire flange.

Happy Motoring
www.TruckMasterDesigns.com